

# **Instructions for the use of: Beam Clamps**

The information in this leaflet must be passed to the user of the equipment, who must be suitably trained in the use of this equipment

This document is issued in accordance with the requirements of Section 6 of the Health and Safety at Work etc Act 1974, amended March 1988 and the Supply of Machinery (Safety) Regulations 2008 (Machinery Directive). It provides instruction to the user with regards to the care and safe use of BEAM CLAMPS.

This information is of a general nature only covering the main points for the safe use of beam clamps intended for use as suspension points for lifting appliances. It may be necessary to supplement this information for specific applications.

## **ALWAYS:**

- Ensure the operator is properly trained to use beam clamps
- Store and handle beam clamps correctly.
- Inspect beam clamps and accessories before use and before placing into storage.
- Ensure the supporting structure is adequate for the full load that will be imposed and suitable for the application.
- Check the clamp is of the correct profile and size, or correctly adjusted, for the beam width and that it seats correctly on the beam flange.
- Ensure the beam clamp is strong enough for the full load that will be imposed.
- Check that the clamp is directly over the centre of gravity of the load.

## **NEVER:**

- Use beam clamps which are unidentified or uncertified for lifting applications.
- Never replace bolts, shackles etc without consulting the supplier.
- Throw or drop beam clamps.
- Use beam clamps on damaged or distorted beams.
- Force or wedge hooks of lifting appliances into the attachment eye or fitting (eg shackle).
- Obliquely load beam clamps without the authority of the supplier.

## **Selecting the Correct Beam Clamp**

Beam clamps are available in a range of capacities and designs. They may be adjustable or of fixed size, have scissor action, screw locking or bolt clamp fixing and be suitable for temporary or permanent applications. Select the beam clamp to be used and plan the lift taking the following into account:

Type of clamp - adjustable/non-adjustable - scissor, screw or bolt action.

Capacity and beam size or range of beam sizes.

Suitability of the beam.

Type of lifting appliance to be used.

If application is temporary or permanent.

*NOTE: Beam clamps are generally intended for attachment to overhead beams to act as suspension points for lifting appliances. Some designs are suitable for attachment to the load to provide a lifting point. The supplier should be consulted for such applications which are excluded from these instructions.*

## **Storing and Handling Beam Clamps**

Never return damaged beam clamps to storage. They should be dry, clean and protected from corrosion. Where necessary fasteners should be reassembled immediately after removal from the beam.

Beam clamps should not be dropped or thrown down.

## **Using Beam Clamps Safely**

The safe use of beam clamps will largely be governed by the requirements for the lifting appliance with which it is to be used but should take the following matters into account:

Do not use defective beam clamps, lifting appliances or accessories.

Ensure the structure from which the clamp is to be suspended is undamaged and is adequate for the full load that will be imposed. If any doubt exists consult a Competent Person to confirm suitability.

Ensure the clamp is suitable for the application, correct size and profile for the beam and seats correctly. It must not cause localised overloading.

Ensure the lifting appliance is compatible with the clamp and that hooks or other attachments fit freely into the eye, shackle etc of the clamp.

The clamp must be positioned directly over the centre of gravity of the load and the load must not be allowed to swing or impose an oblique loading.

If two clamps are to be used in tandem the use of ancillary equipment may also be necessary, eg spreader beam. Care must be taken to ensure no one clamp takes more than its SWL.

## **In-service Inspection and Maintenance**

Beam clamps should be cleaned and any moving parts lubricated at appropriate intervals unless the suppliers specific instructions indicate otherwise.

Regularly inspect the beam clamp, in the event of the following defects refer the clamp to a Competent Person for thorough examination: wear, damage or distortion, cracks, insecure bolts etc, corrosion, illegible markings.

**In the case of re-selling and/or hire of equipment, this information must be passed onto the end user**

Further information can be obtained from:

\* *The Code of Practice for the Safe Use of Lifting Equipment, published by:*



*Some of the above information has been reproduced with the kind permission of LEEA*